


# Canon

## LV-HD420 LV-X420



1. AC IN	Power Input
2. RJ-45	Network connection
3. Mini jack	12V output (trigger for screen operation)
4. HDMI	HDMI input
5. RCA	Video input
6. HDMI/MHL	HDMI/MHL input
7. 2RCA	Audio input (L/R)
8. Mini jack	Audio input (*1)
9. Mini Dsub15	Analog PC output
10. Mini Dsub15	Analog PC / Component input
11. Mini Dsub15	Analog PC / Component input
12. Antitheft lock hole	Connects antitheft wire
13. Dsub9	RS232C connection
14. USB mini B	Service port
15. Mini jack	Audio output
16. Mini jack	Microphone input (*1)
17. Mini DIN4	S-video input
18. USB type A	Power Supply

\*1 Either the audio or microphone input can be enabled at a time.